

- [1]: The first Door Station, the DIP bit-1 and bit-2 should be set to <u>00</u>.
- [2]: The 2nd Door Station, the DIP bit-1 and bit-2 should be set to <u>01</u>.
- [3]: The 3rd Door Station, the DIP bit-1 and bit-2 should be set to 10.
- [4]: The 4th Door Station, the DIP bit-1 and bit-2 should be set to 11.
- [5]: Power Supply MUST be installed side by side with DPS unit.
- [6]: Power Separator, MUST be installed side by side with the [5]
- [7]: VD 04 (4ch video distributor), can connect Max. 4 Door Stations.
- [8]: Monitor, each one with a unique User Code, note that all the bit-6 of the DIP should be set to 1 (on) in this case.(Max.32 Monitors)
- **[9]:** VD O4 (4ch video distributor) unit, the switch of the VD O4 should be set to \underline{HI} except the last one which is at the end of the bus line.

When Monitor quantity < 20

Cable Usage	Α	В	С
Twisted cable 2x0.75 mm ²	60	60	30
Twisted cable 2x1 mm ²	80	80	40

When Monitor quantity > 20

Cable Usage	Α	В	С
Twisted cable 2x1 mm ²	70	30	20
Twisted cable 2x1.5 mm ²	70	50	30